

## HOW-TO-APPLY ROMEX – PROFI-DEKO (Small applications)



1. Prepare surface for hardening by making sure it is compact and stable to a depth of at least 30 mm. Adjoining surfaces that are not to be joint-fixed must be taped off.
2. Thoroughly wash and clean the stones/gravel so that all dirt and debris are removed.
3. Allow the stones/gravel to dry out. We recommend placing them on a plastic sheet in direct sunlight.
4. Place the stones/gravel into a large bucket and add the required amount of resin. One 3kg unit treats approximately 120kg of stone/gravel (9-11mm).
5. Mix vigorously for **at least 6 minutes**.
6. Pour the mix onto the prepared surface; if necessary, disperse it with a shovel and ensure desired depth is achieved.
7. Compact the mixture using a trowel and then smooth off the surface. Good compacting is essential for a durable end product!
8. Allow to dry for 24 hours and make sure that there is no rain during this period.

**ROMEX®**