

HOW-TO-APPLY ROMPOX® - PROFI-DEKO (LARGE APPLICATIONS)

1. MIXING



Pour the clean and dry grit/gravel into the pug mill mixer or concrete mixer and start the mixing process.

2. ADD RESIN



Whilst mixing, slowly add the separately packaged 3 kg resin/hardener component completely into the mixture. Total mixing time: **at least 6 minutes.**

3. APPLY



Pour the mix onto the prepared surface (minimum depth of 30mm); if necessary, disperse it with a shovel and ensure desired depth is achieved.

4. COMPACT



Compact the mixture using a light vibratory plate or smoothing trowel and then smooth off the surface. Good compacting is essential for a durable end product! Allow to dry for 24hrs.

ROMEX®